

## DATALINK & US ROBOTICS 56K FAX/MODEM APPLICATION NOTE

**PROGRAMMING CABLE FOR DL3500: (Standard NULL Modem also works)**

**9 PIN FEMALE                      9 PIN FEMALE**

2-----3  
3-----2  
5-----5

**PROGRAMMING CABLE FOR MODEM:**

**9 PIN FEMALE                      25 PIN MALE**

2-----3  
3-----2  
4-----20  
5-----7  
6-----6  
7-----4  
8-----1  
9-----22

**TO PROGRAM FOR DL3500:    SET DIP SWITCHES 3, 5 & 8 DOWN**

**ENTER THE FOLLOWING:    (EACH SHOULD REPLY OK)**

**AT&F0  
ATY0  
AT&B1&C1&D2&H1&K0&M0&N6&R1&S1&W0  
ATB0&W0  
ATS0=1&W0  
ATS13=1&W0  
ATS19=1&W0**

**TO RUN WITH DL3500: SET DIP SWITCH 3 DOWN**

**DL3500 CHB TO USROBOTICS MODEM CABLE:**

**9 PIN FEMALE                      25 PIN MALE**

2-----3  
3-----2  
4-----20  
5-----7  
7-----4    connect pins 4 & 5 together  
8-----5